

Зип Общепит
vsezip.ru
+7(812)987-08-81





F60PR

Edition 20140115-

vsezip.ru

This diagram illustrates the exploded view of a microwave oven assembly. The main components are labeled with numbers 1 through 125. The assembly includes a microwave cavity (1), a turntable (3) with its support (4), a control panel (66) with various buttons (83, 88, 89, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125), a door (68) with a handle (81) and latch (82), and a base (2) with legs (91). A detailed inset in the upper right corner shows a close-up of the control panel area, highlighting the arrangement of buttons and their corresponding labels (30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125).



Pos	Code	Description	Info
001	30G3190	DOOR ASS. Y	01/01/1998-
002	30M3270	BOTTOM PLATE	01/01/1998-
003	30Q0280	FILTER	01/01/1998-
004	30Q1510	FILTER Ø98 H=117	01/01/1998-
005	30T1340	RIGHT-HAND HINGE	01/01/1998-
006	30T1350	LEFT HAND HINGE	01/01/1998-
007	30T1370	GUIDE	01/01/1998-
008	30W0870	TANK	01/01/1998-
009	36G8540	WASH BLADES 495X58X16	12/06/1999-
010	30Z1491	COMPL. RINSE ARM	14/12/2007-
011	37M8890	NAME PLATE	01/01/1998-
012	37M7200	DOOR TRIM	01/01/1998-
013	3150230	GASKET	01/01/1998-
014	3150290	SUMP GASKET	01/01/1998-
015	3151770	GASKET	01/01/1998-
016	3152010	GASKET	01/01/1998-
017	3190360	PIN	01/01/1998-
018	31W0061	SPRING	16/04/1998-
019	32X0130	GROMMET Ø29-Ø37	01/01/1998-
020	32D0440	CABLE CLAMP	01/01/1998-
021	32D0840	LIVE TERMINAL	01/01/1998-
022	32D0860	GROUND TERMINAL	01/01/1998-
023	33Q4700	LOCK NUT	01/01/1998-
024	32D0850	TERMINAL	01/01/1998-
025	32D1220	TERMINAL CLAMPING BOARD	01/01/1998-
026	32D1230	"OMEGA" BRACKET	01/01/1998-
027	32G0400	HEATING EL.	25/11/1999-
028	3240720	HEATING ELEMENT	01/01/1998-
029	32M4760	MOTOR PUMP	25/11/1999-
030	32W0970	SWITCH	01/01/1998-
031	32W0980	SWITCH	01/01/1998-
032	32W1670	SIGNAL LAMP	01/01/1998-
033	32W0870	MAGNET	01/01/1998-
034	32W3240	MICROSWITCH	01/01/1998-
035	32X0120	GROMMET Ø 21	01/01/1998-
036	32V0200	THERMOSTAT 30° - 90°	01/01/1998-
037	32Z2000	RELAY	01/01/1998-
038	32Z2011	SAFETY THERMOSTAT	01/01/1998-
039	32Z4801	RELAY	01/01/1998-
040	32Z8100	PROGRAMMER	01/01/1998-
041	3300230	DISCHARGE ASPIRATION	01/01/1998-
042	3300240	DISCHARGE	01/01/1998-
043	33D0750	DISPENSER	01/01/1998-
044	33M1280	VENT	25/11/1999-
045	33M0300	SPACER	01/01/1998-
046	33D0660	RINSE AID TANK	01/01/1998-
047	33D1371	INLET WATER SOLENOID VALVE	01/01/1998-
048	33M0350	PIPE	01/01/1998-
049	33M0130	WASHING/RINSE HUB	01/01/1998-
050	33M0170	SUMP	01/01/1998-
051	33M0180	FLANGE	01/01/1998-

Pos	Code	Description	Info
052	33M0490	PIPE	01/01/1998-
053	33M0220	AIR TRAP	01/01/1998-
055	3070540	WASHING INFER. PIPE FITTING	22/05/2006-
056	33M0360	FLANGE	01/01/1998-
057	33M0500	HUB+NUT	01/01/1998-
058	33Q2000	PIN	01/01/1998-
059	33Q1090	PIN	01/01/1998-
060	33Q1860	RING NUT	01/01/1998-
061	33Q1890	PIN	01/01/1998-
063	33M0580	RINSE COUPLING	01/01/1998-
064	34A0290	BOILER	01/01/1998-
065	35A0530	CONTAINER BACK	01/01/1998-
066	35D2750	BOTTOM PANEL	01/01/1998-
067	35D2950	LH SIDE PANEL	01/01/1998-
068	35D2960	RH SIDE PANEL	01/01/1998-
069	35D2990	BACK PANEL	01/01/1998-
070	35D8710	SOL. VALVE SUPPORT	01/01/1998-
071	35G1570	TOP PANEL	01/01/1998-
072	35G2120	DOOR	01/01/1998-
073	35S2290	ELECTRIC BOX	01/01/1998-
074	35S2300	COVER	01/01/1998-
075	35T0610	THERMOSTAT SUPPORT	01/01/1998-
076	131AA14	RUBBER HOSE Ø20x13	01/01/1998-
077	35V8380	PRESSOSTAT SWITCH SUPPORT	01/01/1998-
078	33M0630	STEAM CONDENSER	01/01/1998-
079	3150010	"O" RING	01/01/1998-
080	3601130	CONTROL BOARD	01/01/1998-
081	3601140	DOOR HANDLE	01/01/1998-
082	3601150	SIDE HEAD	01/01/1998-
083	3601190	HANDLE	01/01/1998-
084	33Q2890	JOINT	01/01/1998-
085	32V0100	THERMOSTAT 30°-60°	01/01/1998-
086	36E0010	FOOT	01/01/1998-
087	36G1340	SPRING	01/01/1998-
088	36G2540	SPRING	01/01/1998-
089	36M1511	HANDLE	01/01/1998-
090	37M7170	CTRL BOARD BAND	13/02/1998-
091	35S2830	PUMP SUPPORT	01/01/1998-
092	37Q1320	GASKET	01/01/1998-
093	33Q5180	HOSE SUPPORT	01/01/1998-
094	35Z0050	TRAP PLATE	01/01/1998-
095	33T2820	NOZZLE	01/01/1998-
096	32W2760	CONTACT ELEM.	01/01/1998-
097	32W2960	SWITCH	01/01/1998-
098	32Z2430	THERMOSTAT	01/01/1998-
099	32Z2840	PRESSURE-SWITCH	01/01/1998-
100	32Z8310	AUXILIARY CONTACT	01/01/1998-
101	32Z8510	FILTER	01/01/1998-
102	3128840	WASHER	01/01/1998-
104	3300280	PIPE	01/01/1998-
105	3300420	DRAIN PIPE	01/01/1998-

Pos	Code	Description	Info
107	3300380	PIPE	01/01/1998-
108	33Q2910	"T" JOINT	01/01/1998-
109	131AA23	RUBBER HOSE Ø35 Ø28	01/01/1998-
110	35C8220	PROP. DÉVICE SUPPORT	01/01/1998-
111	3150321	HEAT.ELEM.PROTECTION	01/01/1998-
112	3150520	"O" RING	01/01/1998-
113	33Q4440	DETERGENTCOUPL.	25/11/1999-
114	35E0040	MOTOR PUMP SUPPORT	01/01/1998-
115	3150430	"O" RING Ø 56.52	01/01/1998-
116	36G8540	WASH BLADES	01/01/1998-
117	36G8550	495X58X16 RINSE HUB	01/01/1998-
118	36R0030	PLUG	01/01/1998-
119	33T2740	SPRAYING NOZZLE	01/01/1998-
120	35X4020	RH RINSE ARM	01/01/1998-
121	35X4030	LH RINSE ARM	01/01/1998-
122	32M2920	RINSE PUMP	01/01/1998-
124	33D0140	OVERFLOW	15/01/2014-
125	32Z4741	PRESSURE-SWITCH 30/70	25/11/1999-
126	3150520	"O" RING	01/01/2001-