

Зип Общепит  
vsezip.ru  
+7(812)987-08-81




**BE1A-2**

**Edition 20040907-**

## Зип Общепит

**vsezip.ru**

**+7(812)987-08-81**




# Зип Ощепит

vsezip.ru

+7(812)987-0881

|               |     |                                                |                                       |
|---------------|-----|------------------------------------------------|---------------------------------------|
|               |     | 6BEAM<br>6BEAB<br>6BEAA<br>BE1A<br>6BEAZ       | 6BEA<br>6BEA<br>6BEA<br>BE1A/<br>6BEA |
| Num. Cassetti | 1/2 | --                                             | 2                                     |
| Schublad      |     |                                                |                                       |
| Drawers       | 1/3 | --                                             | --                                    |
| Tiroirs       |     |                                                |                                       |
| Gabetas       | 2/3 | --                                             | --                                    |
|               |     | 6BEB3M<br>6BEB3B<br>6BEB3A<br>BE1B/3<br>6BEB3Z | 6BEC<br>6BEC<br>6BEC<br>BE1C<br>6BEC  |
| Num. Cassetti | 1/2 | --                                             | --                                    |
| Schublad      |     |                                                |                                       |
| Drawers       | 1/3 | 3                                              | --                                    |
| Tiroirs       |     |                                                |                                       |
| Gabetas       | 2/3 | --                                             | --                                    |



Зип Общепит

vsezip.ru

+7(812)987-08-81

|                                                       |    |                                                     |                                      |
|-------------------------------------------------------|----|-----------------------------------------------------|--------------------------------------|
| Porte<br>Ture<br>Doors<br>Portes<br>Portas<br>Gabetas | SX | 6BEAM<br>6BEAB<br>6BEAA<br>BE1A<br>6BEAZ<br>1       | 6BE<br>6BE<br>6BE<br>BE1<br>6BE<br>1 |
|                                                       | DX | 1                                                   | --                                   |
| Porte<br>Ture<br>Doors<br>Portes<br>Portas<br>Gabetas | SX | 6BEB3M<br>6BEB3B<br>6BEB3A<br>BE1B/3<br>6BEB3Z<br>2 | 6BE<br>6BE<br>6BE<br>BE1<br>6BE<br>3 |
|                                                       | DX | --                                                  | 1                                    |

| Page | Pos | Code    | Description          | Info        |
|------|-----|---------|----------------------|-------------|
| 002  | 001 | 30A2880 | CONTROL BOARD        | 01/06/1997- |
| 002  | 002 | 30D4560 | STOPPING COMPON.     | 01/06/1997- |
| 002  | 005 | 35C4430 | SIDE-BACK PANEL      | 01/06/1997- |
| 002  | 006 | 30T6190 | RISER                | 01/06/1997- |
| 002  | 009 | 30T6270 | INSTR/BD BRACKET     | 01/06/1997- |
| 002  | 012 | 32D0020 | CABLE CLAMP Ø 4 - 12 | 01/06/1997- |
| 002  | 013 | 32D0220 | CABLE CLAMP Ø 16     | 01/06/1997- |
| 002  | 014 | 32D0680 | CABLE CLAMP          | 01/06/1997- |
| 002  | 015 | 32D0710 | THREE-POLE CONNECTOR | 01/06/1997- |
| 002  | 016 | 32D0690 | TERMINAL BOARD       | 01/06/1997- |
| 002  | 017 | 32G0240 | HEATING ELEMENT      | 01/06/1997- |
| 002  | 018 | 32M2510 | FAN                  | 01/06/1997- |
| 002  | 019 | 32M6870 | FAN MOTOR            | 05/12/2001- |
| 002  | 020 | 32M5920 | TANGENTIAL FAN       | 23/11/1998- |
| 002  | 023 | 32X0140 | GROMMET Ø13,5-Ø25    | 01/06/1997- |
| 002  | 024 | 32X0340 | GROMMET              | 01/06/1997- |
| 002  | 025 | 32Z7710 | CONDENSER            | 09/04/1999- |
| 002  | 026 | 32Z2750 | COIL                 | 01/06/1997- |
| 002  | 027 | 32V3370 | RELAY                | 09/04/1999- |
| 002  | 028 | 32V3380 | ENGINE CUTOUT        | 09/04/1999- |
| 002  | 032 | 3300030 | CONDENS. DRAIN       | 01/06/1997- |
| 002  | 033 | 33A0510 | DEFROST SOL. VALVE   | 01/06/1997- |
| 002  | 034 | 33A0180 | FILTER               | 01/06/1997- |
| 002  | 035 | 33A1200 | AUXIL.VALVE          | 01/06/1997- |
| 002  | 036 | 33Q5970 | SLEEVE               | 01/06/1997- |
| 002  | 037 | 34D3390 | EVAPORATOR           | 09/04/1999- |
| 002  | 038 | 32Z3420 | CONDENSER            | 01/06/1997- |
| 002  | 039 | 34D5570 | MOTOR UNIT           | 09/04/1999- |
| 002  | 040 | 34D5500 | COMPRESSOR           | 09/04/1999- |
| 002  | 041 | 35B7800 | BOTTOM PANEL         | 01/06/1997- |
| 002  | 042 | 35C4440 | TOP PANEL            | 01/06/1997- |
| 002  | 043 | 35B7840 | INSTR.BOARD RISER    | 01/06/1997- |
| 002  | 044 | 35G7260 | PANEL-BOARD COVER    | 01/06/1997- |
| 002  | 045 | 35Q7970 | PANEL BOARD          | 01/06/1997- |
| 002  | 046 | 35Q7980 | EVAPORATOR GUARD     | 01/06/1997- |
| 002  | 047 | 35T0390 | SPACER PIPE          | 01/06/1997- |
| 002  | 048 | 35U4420 | FAN SUPPORT          | 01/06/1997- |
| 002  | 051 | 35V3300 | SHELF OMEGA          | 01/06/1997- |
| 002  | 053 | 35V3340 | MOT.COMP.RISER       | 01/06/1997- |
| 002  | 054 | 35V3410 | INSTR/BD PLATE       | 01/06/1997- |
| 002  | 055 | 35V3420 | CROSS MEMBER         | 01/06/1997- |
| 002  | 057 | 35V3490 | LH GUIDE             | 01/06/1997- |
| 002  | 058 | 35V3500 | RH GUIDE             | 01/06/1997- |
| 002  | 059 | 35V3510 | TRIM                 | 01/06/1997- |
| 002  | 060 | 35V3540 | CONVEYOR             | 01/06/1997- |
| 002  | 061 | 35V4130 | BACK GUIDE SUPPORT   | 01/06/1997- |
| 002  | 062 | 35V4240 | FOOT-HOLDER OM.      | 01/06/1997- |
| 002  | 064 | 35V4850 | SUPPORT              | 01/06/1997- |
| 002  | 065 | 35V4860 | EVAPORATOR SUPPORT.  | 01/06/1997- |
| 002  | 066 | 35V5200 | TRAY SUPP.           | 01/06/1997- |
| 002  | 068 | 35V6460 | BOTTOM BRACKET       | 01/06/1997- |

| Page | Pos | Code    | Description                 | Info        |
|------|-----|---------|-----------------------------|-------------|
| 002  | 069 | 35V6600 | DRAIN GUARD                 | 01/06/1997- |
| 002  | 070 | 35W4540 | LOWER TRAY                  | 01/06/1997- |
| 002  | 071 | 35W4550 | TRAY                        | 01/06/1997- |
| 002  | 072 | 35X1640 | DRAIN TRAP                  | 01/06/1997- |
| 002  | 073 | 35X2230 | DRAIN                       | 01/06/1997- |
| 002  | 074 | 36D3560 | VERT.FRAME                  | 01/06/1997- |
| 002  | 075 | 36D3610 | BORDER FRAME                | 01/06/1997- |
| 002  | 076 | 36D3860 | TRIM FRAME                  | 01/06/1997- |
| 002  | 077 | 36D4600 | SPACER                      | 01/06/1997- |
| 002  | 080 | 36D5530 | TRIM FRAME                  | 01/06/1997- |
| 002  | 082 | 36E4780 | CONDENS. DRAIN              | 07/09/2004- |
| 002  | 083 | 36C3960 | FOOT                        | 15/11/1999- |
| 002  | 086 | 36Q1400 | PLUG                        | 01/06/1997- |
| 002  | 087 | 36Z0010 | TRAY                        | 01/06/1997- |
| 002  | 088 | 36Z0030 | TRAY                        | 01/06/1997- |
| 002  | 090 | 40A0237 | FRAME                       | 01/06/1997- |
| 002  | 091 | 6006310 | P.C.B. (REFRIG. COUNTERS)   | 01/06/1997- |
| 002  | 092 | 32V0140 | P.C.B.                      | 01/06/1997- |
| 002  | 093 | 32V0150 | TEMP. PROBE                 | 01/06/1997- |
| 002  | 094 | 32V0150 | TEMP. PROBE                 | 01/06/1997- |
| 002  | 095 | 36D9920 | SPACER                      | 01/06/1997- |
| 002  | 096 | 36D9950 | SPACER                      | 01/06/1997- |
| 002  | 097 | 3600850 | PANEL SUPPORT               | 01/06/1997- |
| 002  | 098 | 37M4850 | PLASTIC COATED PANEL        | 01/06/1997- |
| 002  | 099 | 35V7930 | TRAY RESIS. FASTENER        | 01/06/1997- |
| 003  | 003 | 35V4120 | GUIDE SUPPORT               | 01/09/1998- |
| 003  | 004 | 36M5380 | TELESCOPIC LH GUIDE         | 01/09/1998- |
| 003  | 005 | 36M5390 | TELESCOPIC RH GUIDE         | 01/09/1998- |
| 003  | 006 | 36D3400 | DOOR TRIM                   | 01/09/1998- |
| 003  | 007 | 36D3590 | LEFT HEAD                   | 01/09/1998- |
| 003  | 008 | 36D3600 | RIGHT HEAD                  | 01/09/1998- |
| 003  | 009 | 36D3820 | PLUG                        | 01/09/1998- |
| 003  | 011 | 30G2470 | DRAWER UNIT 1/2             | 01/09/1998- |
| 003  | 012 | 30W3160 | DRAWER FRAME                | 01/09/1998- |
| 003  | 013 | 37Q7690 | GASKET                      | 01/09/1998- |
| 003  | 018 | 6000190 | DRAWER REPLACEMENT UNIT 1/2 | 01/09/1998- |
| 004  | 001 | 30G2440 | DOOR                        | 01/09/1998- |
| 004  | 002 | 36D3400 | DOOR TRIM                   | 01/09/1998- |
| 004  | 003 | 36D3590 | LEFT HEAD                   | 01/09/1998- |
| 004  | 004 | 36D3600 | RIGHT HEAD                  | 01/09/1998- |
| 004  | 005 | 36D3820 | PLUG                        | 01/09/1998- |
| 004  | 006 | 37Q7590 | GASKET                      | 01/09/1998- |
| 004  | 007 | 6000210 | LEFT DOOR REPLACEMENT UNIT  | 01/09/1998- |