

KitchenAid®

Зип Общепит

vsezip.ru

VEGETABLE SHEET CUTTER ATTACHMENT

+7(812)987-08-81

MODELS:

KSMSCA0








5KSMSCA0 (International)

VEGETABLE SHEET CUTTER ATTACHMENT

Парты

vsezip.ru

+7(812)987-08-81



VEGETABLE SHEET CUTTER ATTACHMENT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W11131248	Skewer Assembly	6	W11131251	Blade Assembly (Thick)
	W11037727	Use & Care Guide	5	W11131250	Blade Assembly (Thin)			
2	W11131246	Food Holder				7		Main Body (Not Serviced)
3	W11131247	Cucumber Adapter						