

Зип Общепит  
vsezip.ru  
+7(812)987-08-81



**F60PR**

**Edition 20140115-**

vsezip.ru

This diagram shows the exploded view of a refrigerator assembly. The main components are labeled with numbers: 1 (refrigerator body), 2 (base), 3 (bottom panel), 4 (compressor), 5 (door hinge), 6 (door hinge), 7 (door hinge), 8 (door hinge), 9 (door hinge), 10 (door hinge), 11 (door hinge), 12 (door hinge), 13 (door hinge), 14 (door hinge), 15 (door hinge), 16 (door hinge), 17 (door hinge), 18 (door hinge), 19 (door hinge), 20 (door hinge), 21 (door hinge), 22 (door hinge), 23 (door hinge), 24 (door hinge), 25 (door hinge), 26 (door hinge), 27 (door hinge), 28 (door hinge), 29 (door hinge), 30 (door hinge), 31 (door hinge), 32 (door hinge), 33 (door hinge), 34 (door hinge), 35 (door hinge), 36 (door hinge), 37 (door hinge), 38 (door hinge), 39 (door hinge), 40 (door hinge), 41 (door hinge), 42 (door hinge), 43 (door hinge), 44 (door hinge), 45 (door hinge), 46 (door hinge), 47 (door hinge), 48 (door hinge), 49 (door hinge), 50 (door hinge), 51 (door hinge), 52 (door hinge), 53 (door hinge), 54 (door hinge), 55 (door hinge), 56 (door hinge), 57 (door hinge), 58 (door hinge), 59 (door hinge), 60 (door hinge), 61 (door hinge), 62 (door hinge), 63 (door hinge), 64 (door hinge), 65 (door hinge), 66 (door hinge), 67 (door hinge), 68 (door hinge), 69 (door hinge), 70 (door hinge), 71 (door hinge), 72 (door hinge), 73 (door hinge), 74 (door hinge), 75 (door hinge), 76 (door hinge), 77 (door hinge), 78 (door hinge), 79 (door hinge), 80 (door hinge), 81 (door hinge), 82 (door hinge), 83 (door hinge), 84 (door hinge), 85 (door hinge), 86 (door hinge), 87 (door hinge), 88 (door hinge), 89 (door hinge), 90 (door hinge), 91 (door hinge), 92 (door hinge), 93 (door hinge), 94 (door hinge), 95 (door hinge), 96 (door hinge), 97 (door hinge), 98 (door hinge), 99 (door hinge), 100 (door hinge), 101 (door hinge), 102 (door hinge), 103 (door hinge), 104 (door hinge), 105 (door hinge), 106 (door hinge), 107 (door hinge), 108 (door hinge), 109 (door hinge), 110 (door hinge), 111 (door hinge), 112 (door hinge), 113 (door hinge), 114 (door hinge), 115 (door hinge), 116 (door hinge), 117 (door hinge), 118 (door hinge), 119 (door hinge), 120 (door hinge), 121 (door hinge), 122 (door hinge), 123 (door hinge), 124 (door hinge), 125 (door hinge).

Callouts include:

- Top right: 57, 116, 119, 120, 118, 121, 117.
- Bottom right: 49, 13, 56, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125.

| Pos | Code    | Description                | Info        |
|-----|---------|----------------------------|-------------|
| 001 | 30G3190 | DOOR ASS. Y                | 01/01/1998- |
| 002 | 30M3270 | BOTTOM PLATE               | 01/01/1998- |
| 003 | 30Q0280 | FILTER                     | 01/01/1998- |
| 004 | 30Q1510 | FILTER Ø98 H=117           | 01/01/1998- |
| 005 | 30T1340 | RIGHT-HAND HINGE           | 01/01/1998- |
| 006 | 30T1350 | LEFT HAND HINGE            | 01/01/1998- |
| 007 | 30T1370 | GUIDE                      | 01/01/1998- |
| 008 | 30W0870 | TANK                       | 01/01/1998- |
| 009 | 36G8540 | WASH BLADES 495X58X16      | 12/06/1999- |
| 010 | 30Z1491 | COMPL. RINSE ARM           | 14/12/2007- |
| 011 | 37M8890 | NAME PLATE                 | 01/01/1998- |
| 012 | 37M7200 | DOOR TRIM                  | 01/01/1998- |
| 013 | 3150230 | GASKET                     | 01/01/1998- |
| 014 | 3150290 | SUMP GASKET                | 01/01/1998- |
| 015 | 3151770 | GASKET                     | 01/01/1998- |
| 016 | 3152010 | GASKET                     | 01/01/1998- |
| 017 | 3190360 | PIN                        | 01/01/1998- |
| 018 | 31W0061 | SPRING                     | 16/04/1998- |
| 019 | 32X0130 | GROMMET Ø29-Ø37            | 01/01/1998- |
| 020 | 32D0440 | CABLE CLAMP                | 01/01/1998- |
| 021 | 32D0840 | LIVE TERMINAL              | 01/01/1998- |
| 022 | 32D0860 | GROUND TERMINAL            | 01/01/1998- |
| 023 | 33Q4700 | LOCK NUT                   | 01/01/1998- |
| 024 | 32D0850 | TERMINAL                   | 01/01/1998- |
| 025 | 32D1220 | TERMINAL CLAMPING BOARD    | 01/01/1998- |
| 026 | 32D1230 | "OMEGA" BRACKET            | 01/01/1998- |
| 027 | 32G0400 | HEATING EL.                | 25/11/1999- |
| 028 | 3240720 | HEATING ELEMENT            | 01/01/1998- |
| 029 | 32M4760 | MOTOR PUMP                 | 25/11/1999- |
| 030 | 32W0970 | SWITCH                     | 01/01/1998- |
| 031 | 32W0980 | SWITCH                     | 01/01/1998- |
| 032 | 32W1670 | SIGNAL LAMP                | 01/01/1998- |
| 033 | 32W0870 | MAGNET                     | 01/01/1998- |
| 034 | 32W3240 | MICROSWITCH                | 01/01/1998- |
| 035 | 32X0120 | GROMMET Ø 21               | 01/01/1998- |
| 036 | 32V0200 | THERMOSTAT 30° - 90°       | 01/01/1998- |
| 037 | 32Z2000 | RELAY                      | 01/01/1998- |
| 038 | 32Z2011 | SAFETY THERMOSTAT          | 01/01/1998- |
| 039 | 32Z4801 | RELAY                      | 01/01/1998- |
| 040 | 32Z8100 | PROGRAMMER                 | 01/01/1998- |
| 041 | 3300230 | DISCHARGE ASPIRATION       | 01/01/1998- |
| 042 | 3300240 | DISCHARGE                  | 01/01/1998- |
| 043 | 33D0750 | DISPENSER                  | 01/01/1998- |
| 044 | 33M1280 | VENT                       | 25/11/1999- |
| 045 | 33M0300 | SPACER                     | 01/01/1998- |
| 046 | 33D0660 | RINSE AID TANK             | 01/01/1998- |
| 047 | 33D1371 | INLET WATER SOLENOID VALVE | 01/01/1998- |
| 048 | 33M0350 | PIPE                       | 01/01/1998- |
| 049 | 33M0130 | WASHING/RINSE HUB          | 01/01/1998- |
| 050 | 33M0170 | SUMP                       | 01/01/1998- |
| 051 | 33M0180 | FLANGE                     | 01/01/1998- |

| Pos | Code    | Description                 | Info        |
|-----|---------|-----------------------------|-------------|
| 052 | 33M0490 | PIPE                        | 01/01/1998- |
| 053 | 33M0220 | AIR TRAP                    | 01/01/1998- |
| 055 | 3070540 | WASHING INFER. PIPE FITTING | 22/05/2006- |
| 056 | 33M0360 | FLANGE                      | 01/01/1998- |
| 057 | 33M0500 | HUB+NUT                     | 01/01/1998- |
| 058 | 33Q2000 | PIN                         | 01/01/1998- |
| 059 | 33Q1090 | PIN                         | 01/01/1998- |
| 060 | 33Q1860 | RING NUT                    | 01/01/1998- |
| 061 | 33Q1890 | PIN                         | 01/01/1998- |
| 063 | 33M0580 | RINSE COUPLING              | 01/01/1998- |
| 064 | 34A0290 | BOILER                      | 01/01/1998- |
| 065 | 35A0530 | CONTAINER BACK              | 01/01/1998- |
| 066 | 35D2750 | BOTTOM PANEL                | 01/01/1998- |
| 067 | 35D2950 | LH SIDE PANEL               | 01/01/1998- |
| 068 | 35D2960 | RH SIDE PANEL               | 01/01/1998- |
| 069 | 35D2990 | BACK PANEL                  | 01/01/1998- |
| 070 | 35D8710 | SOL. VALVE SUPPORT          | 01/01/1998- |
| 071 | 35G1570 | TOP PANEL                   | 01/01/1998- |
| 072 | 35G2120 | DOOR                        | 01/01/1998- |
| 073 | 35S2290 | ELECTRIC BOX                | 01/01/1998- |
| 074 | 35S2300 | COVER                       | 01/01/1998- |
| 075 | 35T0610 | THERMOSTAT SUPPORT          | 01/01/1998- |
| 076 | 131AA14 | RUBBER HOSE Ø20x13          | 01/01/1998- |
| 077 | 35V8380 | PRESSOSTAT SWITCH SUPPORT   | 01/01/1998- |
| 078 | 33M0630 | STEAM CONDENSER             | 01/01/1998- |
| 079 | 3150010 | "O" RING                    | 01/01/1998- |
| 080 | 3601130 | CONTROL BOARD               | 01/01/1998- |
| 081 | 3601140 | DOOR HANDLE                 | 01/01/1998- |
| 082 | 3601150 | SIDE HEAD                   | 01/01/1998- |
| 083 | 3601190 | HANDLE                      | 01/01/1998- |
| 084 | 33Q2890 | JOINT                       | 01/01/1998- |
| 085 | 32V0100 | THERMOSTAT 30°-60°          | 01/01/1998- |
| 086 | 36E0010 | FOOT                        | 01/01/1998- |
| 087 | 36G1340 | SPRING                      | 01/01/1998- |
| 088 | 36G2540 | SPRING                      | 01/01/1998- |
| 089 | 36M1511 | HANDLE                      | 01/01/1998- |
| 090 | 37M7170 | CTRL BOARD BAND             | 13/02/1998- |
| 091 | 35S2830 | PUMP SUPPORT                | 01/01/1998- |
| 092 | 37Q1320 | GASKET                      | 01/01/1998- |
| 093 | 33Q5180 | HOSE SUPPORT                | 01/01/1998- |
| 094 | 35Z0050 | TRAP PLATE                  | 01/01/1998- |
| 095 | 33T2820 | NOZZLE                      | 01/01/1998- |
| 096 | 32W2760 | CONTACT ELEM.               | 01/01/1998- |
| 097 | 32W2960 | SWITCH                      | 01/01/1998- |
| 098 | 32Z2430 | THERMOSTAT                  | 01/01/1998- |
| 099 | 32Z2840 | PRESSURE-SWITCH             | 01/01/1998- |
| 100 | 32Z8310 | AUXILIARY CONTACT           | 01/01/1998- |
| 101 | 32Z8510 | FILTER                      | 01/01/1998- |
| 102 | 3128840 | WASHER                      | 01/01/1998- |
| 104 | 3300280 | PIPE                        | 01/01/1998- |
| 105 | 3300420 | DRAIN PIPE                  | 01/01/1998- |

| Pos | Code    | Description           | Info        |
|-----|---------|-----------------------|-------------|
| 107 | 3300380 | PIPE                  | 01/01/1998- |
| 108 | 33Q2910 | "T" JOINT             | 01/01/1998- |
| 109 | 131AA23 | RUBBER HOSE Ø35 Ø28   | 01/01/1998- |
| 110 | 35C8220 | PROP. DÉVICE SUPPORT  | 01/01/1998- |
| 111 | 3150321 | HEAT.ELEM.PROTECTION  | 01/01/1998- |
| 112 | 3150520 | "O" RING              | 01/01/1998- |
| 113 | 33Q4440 | DETERGENTCOUPL.       | 25/11/1999- |
| 114 | 35E0040 | MOTOR PUMP SUPPORT    | 01/01/1998- |
| 115 | 3150430 | "O" RING Ø 56.52      | 01/01/1998- |
| 116 | 36G8540 | WASH BLADES           | 01/01/1998- |
| 117 | 36G8550 | 495X58X16 RINSE HUB   | 01/01/1998- |
| 118 | 36R0030 | PLUG                  | 01/01/1998- |
| 119 | 33T2740 | SPRAYING NOZZLE       | 01/01/1998- |
| 120 | 35X4020 | RH RINSE ARM          | 01/01/1998- |
| 121 | 35X4030 | LH RINSE ARM          | 01/01/1998- |
| 122 | 32M2920 | RINSE PUMP            | 01/01/1998- |
| 124 | 33D0140 | OVERFLOW              | 15/01/2014- |
| 125 | 32Z4741 | PRESSURE-SWITCH 30/70 | 25/11/1999- |
| 126 | 3150520 | "O" RING              | 01/01/2001- |