

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
+ 1	SL2924		Knob
2	SL2527		Shaft
+ 3	SL2917		Tap
4	SL2526		Calotte
5	SL2591	ø25xø47x7	Oil seal
6	SL3125	6204 2RS	Bearing
7	SL0082	ø47	Seeger
8	SL2593	ø20xø47x7	Oil seal
9	SL0130		Gear
10	SA2500	Assembly	Calotte
11	SL0125		Gear
12	SL2589		Shaft
13	SA1014	400V/3Ph/50Hz	Stator
13	SA1015	230V/1Ph/50Hz	Stator
14	SL0128		Gear
15	SL0127	ø17xø40x7	Oil seal
16	SL0131	6203 2RS	Bearing
17	SA6700	400V/3Ph/50Hz	Rotor
17	SA6600	230V/1Ph/50Hz	Rotor
18	SL0121	ø5x10	Pin
19	SL0119	ø52	Seeger
20	SL0118	6205 2RS	Bearing
21	SL0117		Calotte
22	SL1841	3Ph+Gnd	Electric cable
22	SL1671	1Ph+N+Gnd	Electric cable
23	SL1668	PG11	Cable clamp
+ 24	SL0106		Grip
25	SA1113		Lever press
26	SL3140		Washer
27	SL3138		Covering
+ 28	SL0885		Microswitch
29	SL0258		Stud

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
30	SL0108		Nut	
31	SL2833		Cover	
32	SL2573		Tap	
33	SA1012	Assembly	Casing	
34	SA2800		Roller	
35	SL0174		Container	
36	SL2988		Base	
+	37	SL0134	Pusher	
	38	SL0136	Hopper	
	39	SL3981	Stainless-steel	Sleeve
	39	SL2553R0	Food stuff treated cast-iron (without CE norms)	Sleeve
	39	SL3982	Unger	Sleeve
	40	SL0180		Container
+	41	SA5300	Stainless-steel	Screw shaft
	41	SA5350	Food stuff treated cast-iron (without CE norms)	Screw shaft
	41	SA2600	Unger	Screw shaft
	42	SL2521		Pivot
	42	SL2561	Unger	Pivot
+	43	////////		Cutter
+	44	////////		Plate
	45	SL0171	Stainless-steel	Handwheel
	45	SL3327R0	Aluminium (without CE norms)	Handwheel
+	46	SL0891	Start-stop	Push button
	47	SL0177	16µF	Condenser
	48	SL0176		Bracket
+	49	SL0883		Electronic card
	50	SL2651		Bottom
	51	SL0235		Foot
	52	SL0054		Switch
	53	SA1119	Assembly - 15/05/05 f.p.(*)	Casing

vsezip.ru

+7(812)987-08-81

