

KitchenAid®

Зип Общепит

vsezip.ru

ORION BLENDER

+7(812)987-08-81

MODELS:




5KSB6060EBM0 (Black Matte - Europe)

5KSB6060EFW0 (Matte White - Europe)

5KSB6060BBM0 (Black Matte - United Kingdom)

5KSB6060BFW0 (Matte White - United Kingdom)

JAR ASSEMBLY PARTS



JAR ASSEMBLY PARTS













<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11051429	Ingredient Cup Assembly	3	W11091749	Jar Assembly	7	W10732358	O-Ring
2	W10703913	Lid, Jar	4	W11091844	Pad, Jar	8	W11095368	Nut, Jar
			5	W10732362	Jar	9	W10793007	Blade
			6	W11031655	Bearing	10	W10842608	Acorn Nut

UNIT PARTS

Зип общепит

vsezip.ru

+7(812)987-08-81



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W10790765	Screw	21		Upper Base
	W11122478	Use & Care Guide	10	W11084721	Electronic Control		W110732367	Black Matte
2	W11089676	Trimband	11	W11049768	Power Cord		W11096376	Matte White
3	W10897392	Rotary Switch	12	W11051447	Tamper	22		Lower Base
4	W11097610	Bezel, Rotary Switch	13	W10703959	Coupler		W11122505	Black Matte
5	W10790752	Screw	14	W10908337	Screw		W11122577	Matte White
6		Knob, Rotary Switch	15	W10811507	Base			
	W11102672	Black Matte	16	W10802704	Seal, Motor			
	W11102670	Matte White	17	W10732360	Motor			
7	W10732369	Toggle LED Lens	18	W10584177	Screw			
8	W10703983	Toggle Switch Assembly	19	3400814	Screw			
			20	3400617	Screw			